



4F-1, 236, Fu-Te 2^{nd} Rd., His Chih,

Taipei Hsien, 221, Taiwan

TEL:886-2-6616-6692 · 2694-6687

FAX:886-2-2694-6875 · 2694-5097

X500 II Control Panel Changing process

Version: 1.0 May 20, 2014



Revision History:

Version	Date	Page	CONTENTS
1.0	May, 20 2014		First version



1. Open the top right cover, and loosen four screws inside, then you can remove the cover of control panel



Then you can see control panel have four screws (see red circles below). Then remove the screws and unplug all cables and then change new one.

