



Innovation
With a Human Touch

4F-1, 236, Fu-Te 2nd Rd., His Chih,

Taipei Hsien, 221, Taiwan

TEL:886-2-6616-6692 · 2694-6687

FAX:886-2-2694-6875 · 2694-5097

X500 II X rollers changing process

Version: 1.0
May 20, 2014

Revision History :

Version	Date	Page	CONTENTS
1.0	May, 20 2014		First release

The estimated life of a set of rollers is about 500 working hours. To change rollers, use flat head screw driver to loose the roller screws. The rollers has spring so it needs to be careful for the spring tension when loosening them. See two arrow below:

